


# DECOWOOD®

## ESTANTERÍA SAURA 3 ÉTAGÈRE SAURA 3


INSTRUCCIONES DE MONTAJE  
ASSEMBLING INSTRUCTIONS  
INSTRUCTIONS D'ASSEMBLAGE



PARTES DEL MUEBLE  
UNIT PARTS  
PARTIES DU MEUBLE



x2\*a



x5\*b

HERRAJES Y PIEZAS  
IRON FITTINGS AND PIECES  
FERRURES ET PIÈCES



x4  
M4x50 \*A



x2 \*B



x4  
M3,5x16 \*C




x4 \*D




x30  
M3,5x40 \*E

MONTAJE  
ASSEMBLING  
MONTAGE


①  
1xa  
1xb  
3xE



②  
1xb  
3xE



③  
3xb  
9xE




# DECOWOOD®

## ESTANTERÍA SAURA 3 ÉTAGÈRE SAURA 3



4

1x a  
15x E



5

2x B  
4x C  
4x D  
4x A



6

