

DECOWOOD®

ESTANTERÍA SAURA 4 ÉTAGÈRE SAURA 4


INSTRUCCIONES DE MONTAJE
ASSEMBLING INSTRUCTIONS
INSTRUCTIONS D'ASSEMBLAGE



PARTES DEL MUEBLE
UNIT PARTS
PARTIES DU MEUBLE



x2 *a



x6 *b

HERRAJES Y PIEZAS
IRON FITTINGS AND PIECES
FERRURES ET PIÈCES



x4
M4x50 *A



x2
*B



x4
M3,5x16 *C




x4 *D




x36
M3,5x40 *E

MONTAJE
ASSEMBLING
MONTAGE


①
1 x a
1 x b
3 x E



②
1 x b
3 x E



③
4 x b
12 x E




DECOWOOD®

ESTANTERÍA SAURA 4 ÉTAGÈRE SAURA 4



4

1x a
18x E



5

2x B
4x C
4x D
4x A



4x C

4x D
4x A

6

