




















5 min




x1




x1



x1





A x1




B x4

1 Atornillar las patas (B x4)
Screw in the legs (B x4)







DECOWOOD®

The change starts here.

www.decowood.com